









Programmeringsark for OPR 2001 / 3201

Program: VASK

SET		
USB HID		SU
Norwegian		PE
UPC-A, Leading zero, transmit CD		E2
Postamble		PS
Enable auto trigger		+I
END	