

ScanPlus 1800 Vare

reset factory defaults



\46\42\60

predefined terminal selections - keyboard wedge - standard PC - QWERTY Norwegian



\41\4A\03\0F\60

keyboard wedge - preamble - compose: BAR



\45\53\22\21\32\60

keyboard wedge - postamble - Enter (*)



\45\54\04\02\01\60

Code 128 / EAN 128 - active



\41\5A\60